

## HCI Link Control Commands

| OGF  | OCF    | Op-code |      |      |                                       |
|------|--------|---------|------|------|---------------------------------------|
| 0x01 | 0x0001 | 0x0401  | V1.1 | V1.2 | Inquiry                               |
| 0x01 | 0x0002 | 0x0402  | V1.1 | V1.2 | Inquiry_Cancel                        |
| 0x01 | 0x0003 | 0x0403  | V1.1 | V1.2 | Periodic_Inquiry_Mode                 |
| 0x01 | 0x0004 | 0x0404  | V1.1 | V1.2 | Exit_Periodic_Inquiry_Mode            |
| 0x01 | 0x0005 | 0x0405  | V1.1 | V1.2 | Create_Connection                     |
| 0x01 | 0x0006 | 0x0406  | V1.1 | V1.2 | Disconnect                            |
| 0x01 | 0x0007 | 0x0407  | V1.1 | —    | Add_SCO_Connection                    |
| 0x01 | 0x0008 | 0x0408  | —    | V1.2 | Create_Connection_Cancel              |
| 0x01 | 0x0009 | 0x0409  | V1.1 | V1.2 | Accept_Connection_Request             |
| 0x01 | 0x000A | 0x040A  | V1.1 | V1.2 | Reject_Connection_Request             |
| 0x01 | 0x000B | 0x040B  | V1.1 | V1.2 | Link_Key_Request_Reply                |
| 0x01 | 0x000C | 0x040C  | V1.1 | V1.2 | Link_Key_Request_Negative_Reply       |
| 0x01 | 0x000D | 0x040D  | V1.1 | V1.2 | PIN_Code_Request_Reply                |
| 0x01 | 0x000E | 0x040E  | V1.1 | V1.2 | PIN_Code_Request_Negative_Reply       |
| 0x01 | 0x000F | 0x040F  | V1.1 | V1.2 | Change_Connection_Packet_Type         |
| 0x01 | 0x0010 | 0x0410  |      |      | <i>not used</i>                       |
| 0x01 | 0x0011 | 0x0411  | V1.1 | V1.2 | Authentication_Requested              |
| 0x01 | 0x0012 | 0x0412  |      |      | <i>not used</i>                       |
| 0x01 | 0x0013 | 0x0413  | V1.1 | V1.2 | Set_Connection_Encryption             |
| 0x01 | 0x0014 | 0x0414  |      |      | <i>not used</i>                       |
| 0x01 | 0x0015 | 0x0415  | V1.1 | V1.2 | Change_Connection_Link_Key            |
| 0x01 | 0x0016 | 0x0416  |      |      | <i>not used</i>                       |
| 0x01 | 0x0017 | 0x0417  | V1.1 | V1.2 | Master_Link_Key                       |
| 0x01 | 0x0018 | 0x0418  |      |      | <i>not used</i>                       |
| 0x01 | 0x0019 | 0x0419  | V1.1 | V1.2 | Remote_Name_Request                   |
| 0x01 | 0x001A | 0x041A  | —    | V1.2 | Remote_Name_Request_Cancel            |
| 0x01 | 0x001B | 0x041B  | V1.1 | V1.2 | Read_Remote_Supported_Features        |
| 0x01 | 0x001C | 0x041C  | —    | V1.2 | Read_Remote_Extended_Features         |
| 0x01 | 0x001D | 0x041D  | V1.1 | V1.2 | Read_Remote_Version_Information       |
| 0x01 | 0x001E | 0x041E  |      |      | <i>not used</i>                       |
| 0x01 | 0x001F | 0x041F  | V1.1 | V1.2 | Read_Clock_Offset                     |
| 0x01 | 0x0020 | 0x0420  | —    | V1.2 | Read_LMP_Handle                       |
| 0x01 | 0x0021 | 0x0421  |      |      | <i>not used</i>                       |
| 0x01 | 0x0022 | 0x0422  |      |      | <i>not used</i>                       |
| 0x01 | 0x0023 | 0x0423  |      |      | <i>not used</i>                       |
| 0x01 | 0x0024 | 0x0424  |      |      | <i>not used</i>                       |
| 0x01 | 0x0025 | 0x0425  |      |      | <i>not used</i>                       |
| 0x01 | 0x0026 | 0x0426  |      |      | <i>not used</i>                       |
| 0x01 | 0x0027 | 0x0427  |      |      | <i>not used</i>                       |
| 0x01 | 0x0028 | 0x0428  | —    | V1.2 | Setup_Synchronous_Connection          |
| 0x01 | 0x0029 | 0x0429  | —    | V1.2 | Accept_Synchronous_Connection_Request |
| 0x01 | 0x002A | 0x042A  | —    | V1.2 | Reject_Synchronous_Connection_Request |

---

