

HCI Link Policy Commands

OGF	OCF	Op-code			
0x02	0x0001	0x0801	V1.1	V1.2	Hold_Mode
0x02	0x0002	0x0802			<i>not used</i>
0x02	0x0003	0x0803	V1.1	V1.2	Sniff_Mode
0x02	0x0004	0x0804	V1.1	V1.2	Exit_Sniff_Mode
0x02	0x0005	0x0805	V1.1	V1.2	Park_Mode
0x02	0x0006	0x0806	V1.1	V1.2	Exit_Park_Mode
0x02	0x0007	0x0807	V1.1	V1.2	QoS_Setup
0x02	0x0008	0x0808			<i>not used</i>
0x02	0x0009	0x0809	V1.1	V1.2	Role_Discovery
0x02	0x000A	0x080A			<i>not used</i>
0x02	0x000B	0x080B	V1.1	V1.2	Switch_Role
0x02	0x000C	0x080C	V1.1	V1.2	Read_Link_Policy_Settings
0x02	0x000D	0x080D	V1.1	V1.2	Write_Link_Policy_Settings
0x02	0x000E	0x080E	—	V1.2	Read_Default_Link_Policy_Settings
0x02	0x000F	0x080F	—	V1.2	Write_Default_Link_Policy_Settings
0x02	0x0010	0x0810	—	V1.2	Flow_Specification